



One device. Endless possibilites.

RaySafe 452 Radiation Survey Meter


As versatile as you are






As versatile as you are.

One device for every situation means less to carry, learn and administrate. That equals less expense, more efficiency and time savings.



There are three models to cover your needs. The full version of the RaySafe 452 measures air kerma, ambient dose equivalent and works as a contamination monitor capable of measuring not only X-ray but also alpha, beta and gamma radiation.



Visit **flukebiomedical.com/452** for videos, detailed specifications, white papers and other information.

Typical applications

The versatile RaySafe 452 Survey Meter can be used for many applications including these:

- X-ray tube leakage
- X-ray wall leakage
- Scattered room radiation
- Contamination measurements
- Environmental radiation
- Non-destructive testing

Fluke Biomedical.

Trusted for the measurements that matter.

Fluke Biomedical 6920 Seaway Blvd, Everett, WA 98203 U.S.A.

For more information, contact us at:

(800) 850-4608 or Fax (440) 349-2307 Email: sales@flukebiomedical.com Web access: www.flukebiomedical.com

©2019 Fluke Biomedical. Specifications subject to change without notice. Printed in U.S.A. 6/2019 6011952a-en

Modification of this document is not permitted without written permission from Fluke Corporation.