



Gx adapter for RaySafe Xi light detector



Mount the RaySafe Gx adapter to the RaySafe light detector according to the illustration.

Attach the Gx adapter to the Image Intensifier light output.



Turn on the meter and select Gx from the sensor menu.

The RaySafe Xi now measures light output in cd/m^2 .